


# Mobile Device & OS Compatibility

[Click here for English](#)

[Haga clic aquí para ver la versión en español](#)

# MOBILE DEVICE & OS COMPATIBILITY

Popular mobile devices and operating systems (OS) are regularly tested to evaluate NFC scan performance, Bluetooth connectivity, and app compatibility with Sensors. Refer to the diagram for the NFC scan location on your mobile device. We recommend checking this guide before installing a new OS version on your phone or before using the App with a new phone.



## Compatible devices and operating systems

### FreeStyle Libre 2 (version 2.7.7)

OS	DEVICE	NFC LOCATION
iOS: 15.5, 15.6, 15.6.1, 15.7, 16, 17, 17.0.1, 17.0.2, 17.0.3, 17.1, 17.1.1, 17.1.2, 17.2, 17.3, 17.3.1	iPhone 7, 7 Plus, 8, 8 Plus, X, XR, XS, XS Max, 11, 11 Pro, 11 Pro Max, 12, 12 Pro, 12 Pro Max, 12 Mini, SE (2020), SE (2022), 13, 13 Pro, 13 Pro Max, 13 Mini, 14, 14 Plus, 14 Pro, 14 Pro Max	1

### FreeStyle Libre 2 (version 2.7.7)

OS	DEVICE	NFC LOCATION
Android: 8*, 8.1*, 9*, 10*, 11, 12, 12.1, 13, 14	Google Pixel, Pixel 2, Pixel 2 XL, Pixel 3, Pixel 4 XL	1
	Google Pixel 3 XL, Pixel 3a, Pixel 4, Pixel 4a, Pixel 4a 5G, Pixel 5, Pixel 6, Pixel 6 Pro, Pixel 6a, Pixel 7, Pixel 7 Pro	2
Android: 8*, 8.1*, 9*, 10*, 11, 12, 12.1, 13	Samsung Galaxy A7, A10, A12, A13 5G, A15 5G, A20, A21, A22, A22 5G, A23, A30, A32, A32 5G, A40, A41, A52, A70, A71, A71 5G, A72, Feel2, Note10 Lite, S7, S10 Lite	1
	Dialn G65	
	Fujitsu Arrows 5G	
	Huawei P30 Pro	
	Kyocera Torque G04	
	LG Nexus 5X	
	Motorola moto g60s	
	Sony Xperia 1 II, Xperia 1 III, Xperia Ace II	
	Sharp AQUOS sense3, zero 2	
	Xiaomi 11 Lite 5G NE, 11T, Redmi Note 8 PRO, Redmi Note 9, Redmi Note 9T, Redmi Note 10 5G, Redmi Note 10 PRO	
Samsung Galaxy A20e, A42 5G, A52 5G, A52s 5G, J6, Note8, Note9, Note10, Note10+, Note20 5G, Note20 Ultra 5G, S7 Edge, S8, S8+, S9, S10, S10 5G, S10+, S10e, S20, S20 FE, S20 FE 5G, S21 5G, S21 5G Olympic Games Edition, S21 FE 5G, S21+ 5G, S22, S22 Ultra, S23, S23 Ultra, Z Fold2 5G, Z Fold3 5G, Z Fold4	2	
FOXXD MIRO+		
Huawei P20 Pro		
Motorola moto g51 5G, one 5G ace		
Sony Xperia 5, Xperia 8, Xperia 10 II		
Sharp AQUOS sense3 plus		
Tinno Rakuten Hand, Rakuten Mini		
Xiaomi 11T Pro, Mi Note 10 Lite		
Galaxy Note10+ 5G, S9+, S20 5G, S20 Ultra 5G, S20+, S20+ 5G, S21 Ultra 5G, S22+, Z Flip3 5G, Z Flip4, Z Flip5, Z Fold5		
LG style2, style3		
Sharp AQUOS R6	3	

### FreeStyle LibreLink (version 2.11.2)

OS	DEVICE	NFC LOCATION
iOS: 15.5, 15.6, 15.6.1, 15.7, 16, 16.0.2, 16.1, 17, 17.0.1, 17.0.2, 17.0.3, 17.1, 17.1.1, 17.1.2, 17.2, 17.3, 17.3.1	iPhone 8, 8 Plus, X, XR, XS, XS Max, 11, 11 Pro, 11 Pro Max, 12, 12 Pro, 12 Pro Max, 12 Mini, SE (2020), 13, 13 Mini, 13 Pro, 13 Pro Max, SE (2022), 14, 14 Plus, 14 Pro, 14 Pro Max	1

### FreeStyle LibreLink (version 2.11.2)


OS	DEVICE	NFC LOCATION
Android: 8*, 8.1*, 9*, 10*, 11, 12, 13, 14	Google Pixel, Pixel 2, Pixel 2 XL, Pixel 3, Pixel 4XL	1
	Google Pixel 3 XL, Pixel 4, Pixel 4a 5G, Pixel 5, Pixel 6, Pixel 6a, Pixel 6 Pro, Pixel 7, Pixel 7 Pro	2
Android: 8*, 8.1*, 9*, 10*, 11, 12, 13	Samsung Galaxy A7, A10, A12, A13 5G, A15 5G, A21, A21 シンプル, A22, A22 5G, A23, A30, A32, A32 5G, A33 5G, A40, A41, A50, A51, A52, A53 5G, A70, A71, A71 5G, A72, Feel2, Note10 Lite, S7, S10 Lite	1
	ASUS Zenfone 8	
	Dialn G65	
	Fujitsu Arrows 5G	
	HTC Desire 22 Pro	
	Kyocera Torque G04	
	OPPO Reno3 A, Reno5 A	
	Sharp AQUOS R3, sense 3, sense 3 plus サウンド	
	Sony Xperia 1 II, Xperia Ace II	
	Xiaomi Redmi Note 9T, Redmi Note 10 5G, 11 Lite 5G NE	
Samsung Galaxy A20, A20e, A52 5G, A52s 5G, Note8, Note9, Note10, Note10+, Note20 5G, Note20 Ultra 5G, S7 Edge, S8, S8+, S9, S10, S10 5G, S10e, S10+, S20, S20 5G, S20 FE 5G, S20+ 5G, S20 Ultra 5G, S21 5G, S21 5G Olympic Games Edition, S21+ 5G, S22, S22+, S22 Ultra, S23, S23 Ultra, Z Fold2 5G, Z Fold3 5G, Z Fold4	2	
Fujitsu Arrows U		
Huawei P20 Pro		
Motorola moto g51 5G		
OPPO Reno A		
Sharp AQUOS sense3 plus		
Sony Xperia 5, Xperia 8		
Tinno Rakuten Hand		
Samsung Galaxy M31, Note10+ 5G, S9+, S20+, Z Flip3 5G, Z Flip4, Z Flip5, Z Fold5		
LG style3		
Sharp AQUOS R6	3	

This guide will be updated as other devices and operating systems are evaluated. The contents of this guide are the most up to date and may be different from what is displayed within the FreeStyle Libre 2 app. Contact Customer Service for more information on devices and operating systems other than those listed. Beta OS versions are not evaluated or supported. The App cannot be used with jailbroken and rooted devices.

\* Please check that your mobile device and OS continues to be supported by the manufacturer. Use of an unsupported mobile device or OS version may affect App security and functionality. You are responsible for the risks associated with the use of the App on an unsupported mobile device or OS version.

# COMPATIBILIDAD CON DISPOSITIVOS MÓVILES Y SISTEMAS OPERATIVOS

Los dispositivos móviles y sistemas operativos más populares se prueban regularmente para evaluar el rendimiento del escaneo NFC, la conectividad Bluetooth y la compatibilidad de las aplicaciones con los sensores. Consulte el diagrama para conocer la ubicación del escáner NFC en su dispositivo móvil. Le recomendamos que consulte esta guía antes de instalar una nueva versión del sistema operativo en su teléfono o antes de utilizar la aplicación con un nuevo teléfono.



UBICACIÓN NFC

## Dispositivos y sistemas operativos compatibles

### FreeStyle Libre 2 (versión 2.7.7)

SISTEMA OPERATIVO	DISPOSITIVO	UBICACIÓN NFC
iOS: 15.5, 15.6, 15.6.1, 15.7, 16, 17, 17.0.1, 17.0.2, 17.0.3, 17.1, 17.1.1, 17.1.2, 17.2, 17.3, 17.3.1	iPhone 7, 7 Plus, 8, 8 Plus, X, XR, XS, XS Max, 11, 11 Pro, 11 Pro Max, 12, 12 Pro, 12 Pro Max, 12 Mini, SE (2020), SE (2022), 13, 13 Pro, 13 Pro Max, 13 Mini, 14, 14 Plus, 14 Pro, 14 Pro Max	1

### FreeStyle Libre 2 (versión 2.7.7)

SISTEMA OPERATIVO	DISPOSITIVO	UBICACIÓN NFC
Android: 8*, 8.1*, 9*, 10*, 11, 12, 12.1, 13, 14	Google Pixel, Pixel 2, Pixel 2 XL, Pixel 3, Pixel 4 XL	1
	Google Pixel 3 XL, Pixel 3a, Pixel 4, Pixel 4a, Pixel 4a 5G, Pixel 5, Pixel 6, Pixel 6 Pro, Pixel 6a, Pixel 7, Pixel 7 Pro	2
Android: 8*, 8.1*, 9*, 10*, 11, 12, 12.1, 13	Samsung Galaxy A7, A10, A12, A13 5G, A15 5G, A20, A21, A22, A22 5G, A23, A30, A32, A32 5G, A40, A41, A52, A70, A71, A71 5G, A72, Feel2, Note10 Lite, S7, S10 Lite  Dialn G65  Fujitsu Arrows 5G  Huawei P30 Pro  Kyocera Torque G04  LG Nexus 5X  Motorola moto g60s  Sony Xperia 1 II, Xperia 1 III, Xperia Ace II  Sharp AQUOS sense3, zero 2  Xiaomi 11 Lite 5G NE, 11T, Redmi Note 8 PRO, Redmi Note 9, Redmi Note 9T, Redmi Note 10 5G, Redmi Note 10 PRO	1
	Samsung Galaxy A20e, A42 5G, A52 5G, A52s 5G, J6, Note8, Note9, Note10, Note10+, Note20 5G, Note20 Ultra 5G, S7 Edge, S8, S8+, S9, S10, S10 5G, S10+, S10e, S20, S20 FE, S20 FE 5G, S21 5G, S21 5G Olympic Games Edition, S21 FE 5G, S21+ 5G, S22, S22 Ultra, S23, S23 Ultra, Z Fold2 5G, Z Fold3 5G, Z Fold4	2
	FOXDX MIRO+  Huawei P20 Pro  Motorola moto g51 5G, one 5G ace  Sony Xperia 5, Xperia 8, Xperia 10 II  Sharp AQUOS sense3 plus  Tinno Rakuten Hand, Rakuten Mini  Xiaomi 11T Pro, Mi Note 10 Lite	
Android: 8*, 8.1*, 9*, 10*, 11, 12, 12.1, 13	Galaxy Note10+ 5G, S9+, S20 5G, S20 Ultra 5G, S20+, S20+ 5G, S21 Ultra 5G, S22+, Z Flip3 5G, Z Flip4, Z Flip5, Z Fold5  LG style2, style3  Sharp AQUOS R6	3

### FreeStyle LibreLink (versión 2.11.2)

SISTEMA OPERATIVO	DISPOSITIVO	UBICACIÓN NFC
iOS: 15.5, 15.6, 15.6.1, 15.7, 16, 16.0.2, 16.1, 17, 17.0.1, 17.0.2, 17.0.3, 17.1, 17.1.1, 17.1.2, 17.2, 17.3, 17.3.1	iPhone 8, 8 Plus, X, XR, XS, XS Max, 11, 11 Pro, 11 Pro Max, 12, 12 Pro, 12 Pro Max, 12 Mini, SE (2020), 13, 13 Mini, 13 Pro, 13 Pro Max, SE (2022), 14, 14 Plus, 14 Pro, 14 Pro Max	1

### FreeStyle LibreLink (versión 2.11.2)

SISTEMA OPERATIVO	DISPOSITIVO	UBICACIÓN NFC
Android: 8*, 8.1*, 9*, 10*, 11, 12, 13, 14	Google Pixel, Pixel 2, Pixel 2 XL, Pixel 3, Pixel 4XL	1
	Google Pixel 3 XL, Pixel 4, Pixel 4a 5G, Pixel 5, Pixel 6, Pixel 6a, Pixel 6 Pro, Pixel 7, Pixel 7 Pro	2
Android: 8*, 8.1*, 9*, 10*, 11, 12, 13	Samsung Galaxy A7, A10, A12, A13 5G, A15 5G, A21, A21 シンプル, A22, A22 5G, A23, A30, A32, A32 5G, A33 5G, A40, A41, A50, A51, A52, A53 5G, A70, A71, A71 5G, A72, Feel2, Note10 Lite, S7, S10 Lite  ASUS Zenfone 8  Dialn G65  Fujitsu Arrows 5G  HTC Desire 22 Pro  Kyocera Torque G04  OPPO Reno3 A, Reno5 A  Sharp AQUOS R3, sense 3, sense 3 plus サウンド  Sony Xperia 1 II, Xperia Ace II  Xiaomi Redmi Note 9T, Redmi Note 10 5G, 11 Lite 5G NE	1
	Samsung Galaxy A20, A20e, A52 5G, A52s 5G, Note8, Note9, Note10, Note10+, Note20 5G, Note20 Ultra 5G, S7 Edge, S8, S8+, S9, S10, S10 5G, S10e, S10+, S20, S20 5G, S20 FE 5G, S20+ 5G, S20 Ultra 5G, S21 5G, S21 5G Olympic Games Edition, S21+ 5G, S22, S22+, S22 Ultra, S23, S23 Ultra, Z Fold2 5G, Z Fold3 5G, Z Fold4	2
	Fujitsu Arrows U  Huawei P20 Pro  Motorola moto g51 5G  OPPO Reno A  Sharp AQUOS sense3 plus  Sony Xperia 5, Xperia 8  Tinno Rakuten Hand	
Android: 8*, 8.1*, 9*, 10*, 11, 12, 13	Samsung Galaxy M31, Note10+ 5G, S9+, S20+, Z Flip3 5G, Z Flip4, Z Flip5, Z Fold5  LG style3  Sharp AQUOS R6	3

Esta guía se actualizará a medida que se evalúen otros dispositivos y sistemas operativos. El contenido de esta guía es el más actualizado y puede diferir de lo que se muestra en la aplicación FreeStyle Libre 2. Comuníquese con el Servicio de atención al cliente para obtener más información sobre dispositivos y sistemas operativos diferentes a los enumerados. No se evalúan ni se brinda soporte a las versiones beta de los sistemas operativos. No se puede usar la aplicación con dispositivos que tengan hecho el jailbreak o rooteados.

\* Consulte si el fabricante sigue brindando soporte a su dispositivo móvil y al sistema operativo. El uso de un dispositivo móvil o de una versión del sistema operativo sin soporte puede afectar la seguridad y el funcionamiento de la aplicación. Usted es responsable de los riesgos asociados al uso de la aplicación en un dispositivo móvil o versión del sistema operativo sin soporte.